AV user guide:



















9

Power button

Press this to start the system

Input source buttons

Press the button labelled with the source you want to present content from

Volume control dial

Use this to adjust room audio volume



Shut-down button Press this to turn the

system off

Camera Preview Button

Press this to see the room video camera orientation on the lectern display and projection screen

Freeze Button

Press this to freeze the projected image while the lectern display remains unfrozen. The red LED will flash while this function is active

Mute button

Press this to mute all audio output. The red LED will remain lit while this function is active