

AV user guide: touch screen functions

ICT

Start up the system - If the screen is blank, touch it to wake it up

Source Control
Select the input source you want to share with the audience

Preview Button
For checking camera view pre-sets

Source Status Area
This indicates the currently selected input source

Volume Slider
For adjusting room volume levels

Room Sound Mute Control
This mutes all room audio output

Date and time

Radio Microphone Status
On
Charging
Out of range

Projector Mute Controls
Show / Hide the projected image

Radio Microphone Mute control

Shut-down Button

The interface features a top menu with source options: PC, Blu-ray, Visualizer, Laptop HDMI, Laptop VGA, and Composite. A central display area shows 'No Source Selected' and 'Please select a source above to begin.' The right side includes a volume slider and a 'Mute Sound' button. The bottom status bar displays the date and time (2 Sep 2022, 9:05 AM), two radio microphone status indicators (1 and 2), projector on/off controls, a 'Mute All' microphone button, and a red power button.